RhinoPRO® 5000   Quick Reference

This Quick Reference gives you an overview of the features and functions of the DYMO RhinoPRO 5000 printer. For more detailed information on using your printer, refer to the *DYMO RhinoPRO 5000 User Guide.*

Function Keys

Function Key	Description
(power)	Toggle power on and off.
(navigation)	Navigate the label and menus.
(enter)	Add new line to label; select a menu option.
(Print)	Print label.
CAPS	Toggle CAPS on or off.
ESC	Exit current activity.
▲	Select alternate function on keys.
▲ + ESC	Toggle display backlight on and off.
←	Delete character to left of cursor.
▲ + ←	Clear current label text & format.
SPACE	Add one space in label text.
▲ + SPACE	Select symbol characters.
SIZE	Select font size.
▲ + SIZE	Select language.
▲ + RECALL	Advance label tape 0.25" (6 mm).
▲ + SAVE	Adjust print quality.

Hot Keys

Hot Key	Steps
WRAP Wrap-around label	1. Enter starting text. 2. Press WRAP. 3. Select label type; then ↵. 4. Press (Print).
FIXED Fixed-length label	1. Enter text and press FIXED. 2. Press ▲ or ▼, and then ↵. 3. Press (Print).
PPANEL Patch panel label	1. Enter starting text. 2. Press PPANEL. 3. Enter distance; then ↵. 4. Press SERIAL. 5. Enter # increments. 6. Press ↵ or (Print).
TBLOCK Terminal block label	1. Enter starting text. 2. Press TBLOCK. 3. Enter distance; then ↵. 4. Press SERIAL. 5. Enter # increments. 6. Press ↵ or (Print).
VERT Vertical label	1. Enter label text. 2. Press VERT; then (Print).
▲ + VERT Barcode	1. Press ▲ + VERT. 2. Choose type, and press ↵. 3. Enter text for barcode (▮▮▮), and then press ↵. 4. Press (Print).

Symbols

To add ...	Do this ...
Commonly used symbols	1. Press symbol key: [Ω] [⏚] [☎] [💻] [🖨]
Symbols from symbol table	1. Press ▲ + [SPACE]. 2. Select symbol; then press ↵.

Symbol Table

Row	Use arrow keys to select										
A	,	(	)	;	'	"	\	=	²	º	&	?
B	←	→	↑	↓	⛏	◀	▱	∅	*	_	@	±

Memory

To ...	Do this ...
Save a label to memory	1. Press SAVE. 2. Select location; then press ↵.
Recall a label from memory	1. Press RECALL. 2. Select a label; then press ↵.
Clear memory location	1. Press RECALL and select location. 2. Press ▲ + ⟵ ; then ↵.

Printing

To print ...	Do this ...
Single label	1. Enter text; then press (Print).
Multiple copies of same label	1. Enter text. 2. Press ▲ + (Print). 3. Enter # copies; then ↵. 4. Press (Print).
Serialized labels	1. Enter the text and numbers. 2. Press ◀ or ▶ to select letter or number to serialize. 3. Press SERIAL. 4. Press ▲ or ▼ to set increment; then ↵ or (Print).

RhinoPRO Label Cassettes

The following industrial label cassettes are available for the RhinoPRO 5000 printer.

Material Type	3/8" (9 mm)	1/2" (12 mm)	3/4" (19 mm)	Length
Flexible Nylon White	—	18488	18489	11.5' (3.5 m)
Flexible Nylon Yellow	—	18490	18491	11.5' (3.5 m)
Permanent Polyester White	18482	18483	18484	18.0' (5.5 m)
Permanent Polyester Metallic	18485	18486	18487	18.0' (5.5 m)