


This Quick Reference gives you an overview of the features and functions of the DYMO RhinoPRO 1000 Label printer. For more detailed information on using your printer, refer to the *DYMO RhinoPRO 1000 User Guide*.

Function Keys

Function Key	Description
	Toggle power on and off.
	Navigate the label and menus.
	Add new line to label; select a menu option.
	Print label.
	Toggle CAPS on or off.
	Shift or select alternate key function.
	Delete character to left of cursor.
	Clear current label text & format.
	Add one space in label text.
	Select symbol characters.
	Select font size.
	Select language.
	Select normal, italic, or outline.
	Adjust print quality.

Printing

To print ...	Do this ...
Single label	<ol style="list-style-type: none"> 1. Enter text. 2. Press .
Multiple copies of same label	<ol style="list-style-type: none"> 1. Enter text. 2. Press . 3. Enter # copies; then . 4. Press .
 Serialized labels	<ol style="list-style-type: none"> 1. Enter the text with at least one number. 2. Press  and use the arrow keys to turn on. 3. Press  or . 4. Repeat step 3 for each additional label in series.

Hot Keys

Hot Key	Steps
 Flag label	<ol style="list-style-type: none"> 1. Enter label text. 2. Press  and then . 3. Press .
 Fixed-length label	<ol style="list-style-type: none"> 1. Enter text and press . 2. Press . 3. Press  and then .
 Vertical label	<ol style="list-style-type: none"> 1. Enter label text. 2. Press  and use arrow keys to select ON. 3. Press .

Symbols

To add ...	Do this ...
Commonly used symbols	1. Press a symbol Hot Key: <div style="display: flex; justify-content: space-around; align-items: center;"> A/V ELECTRICAL SAFETY </div>
Symbols from the symbol table	1. Press + SPACE . 2. Select symbol. 3. Press .

Symbol Table

A	!	i	?	¿	.	,
B	'	#	%	&	;	"
C	+	=	*	-	:	/
D	()	~	\	@	±
E	\$	£	¢	\$	¼	½
F	↓	↑	→	←		

A/V Audio Visual Symbols

ELECTRICAL Electrical Symbols

SAFETY Safety Symbols

--	--	--	--	--

RhinoPRO Industrial Label Cassettes

The following industrial label cassettes are available for the RhinoPRO 1000 printer.

Material Type	3/8" (9 mm)	1/2" (12 mm)	Length
Flexible Nylon White	—	18488	11.5' (3.5 m)
Flexible Nylon Yellow	—	18490	11.5' (3.5 m)
Permanent Polyester White	18482	18483	18.0' (5.5 m)
Permanent Polyester Metallic	18485	18486	18.0' (5.5 m)

SANFORD
BRANDS

www.sanford.com

Produced by:

DYMO Corp., Stamford CT ©2006
800-426-7827: www.dymo.com

A Division of Newell Rubbermaid